



D10 Demonstration Board



Contents

Demonstration Board description	3
Measurement technology - Disturbance immunity	4
E1 Immunity Development System	4
P1 Mini Burst Field Generators	8
H2 - H3 Field Source sets for burst generators	9
PT4 Burst Transformer	10
Optical Fiber Probe (digital OSE)	11
Optical Fiber Probe (analog A)	12
Measurement technology - Disturbance emission	15
RF Near-Field Probes	15
LF Near-Field Probes	17
ESA1 Emission Development System	18

Demonstration Board description



Measurement technology - Disturbance immunity

E1 Immunity Development System


Injection of disturbance current with SGZ 21:

Stimulation of the critical faults by:
Injecting disturbance current into the
natural disturbance current paths and thus


- simulating compliance test conditions
- distinguishing between faults caused by
disturbance current and electric fields

Two-pole injection:
High disturbance current
(fault to LED5)
Small electric fields

Disturbance current can be injected
at any corner (GND)



Single-pole injection:
Large electric fields
(fault to LED4)
Low disturbance currents:
depending on connecting
point (fault to LED5)




Attention!

Do not connect SGZ 21 directly to
IC pins and signal lines!


Search for fault locations with field sources

BS 04 DB magnetic field probe:



Interference:
LED5


BS 04 DB magnetic field probe:



Interference:
LED7

BS 05 DU magnetic field probe:


Determining the lines' susceptibility



Interference:
LED5

ES 05 D electric field probe:

Determining the lines' susceptibility



Interference:
LED4

Signal transfer with S21 sensor

Objective:

Evaluation of modifications on the module and/or in the field of shielding/ filtering

Procedure:


- Connect a sensor to the line likely to be disturbed and link this to SGZ 21 via an optical fiber.
- The SGZ 21 counter displays the number of pulses on the connected line.
- The module is disturbed (as described on page 6). Evaluate any additional pulses on the line:
- The smaller the number of (disturbance) pulses the better the module.
- The efficiency of modifications becomes visible after a measuring time of 1 sec.

Note:


In practice the sensor is attached to the module with super glue via a three-pole socket (several are included in the scope of delivery) and connected with CuL wire.

Example: Interference through disturbance current

Feed the disturbance current through the equipment under test (DUT) via a two-pole connection.



Plug the S21 sensor into socket 5 and connect it to the SGZ 21 generator via an optical fiber; switch on the generator and read the numerical value displayed by the counter



Magnetic field measurement with MSA 02

Objective:

Detection of magnetic fields during burst interference

Where is the DUT exposed to particularly high stress through magnetic fields?

Lead the burst current through the DUT to take measurements, connect MSA 02 to SGZ 21 via an optical fiber, adjust a medium amplification, switch on MSA 02 and take measurements.

The higher the numerical value the greater the average magnetic field intensity.

Attention:



Try to hold the probe head flatly over the DUT as shown in the picture.

Example:

Interference through disturbance current


Feed the disturbance current through the DUT via a two-pole connection and measure the magnetic fields of the disturbance current at the same time.

MSA 02 magnetic field probe with 05R probe head (white)




P1 Mini Burst Field Generators

Coupling of magnetic fields
in signal line loops
with P11 (red)



Fault to **LED5**, beep,
measurement via sensor

Evaluating the susceptibility
of IC inputs
with P12 (yellow)



Fault to **LED5**, beep,
measurement via sensor


Coupling of electric fields
in signal lines
with P21 (blue)



Fault to **LED4**,
measurement via sensor


H2 - H3 Field Source sets for burst generators

BS 04 DB magnetic field probe :



Interference:
LED5


BS 04 DB magnetic field probe:



Interference:
LED7


BS 05 DU magnetic field probe:

Determining the lines' susceptibility



Interference:
LED5

ES 05 D electric field probe:



Interference:
LED4

Attention: The set polarity of the disturbance quantity influences the measurement result. Please always use the supplied connecting cable (dielectric strength).

PT4 - EFT Generator

Connect PT4 to GND via both cables.
A disturbance current flows through both modules.
Fault to **LED5** and **LED7**.


Other variants:

- Only inject disturbance current into individual sections and/or in different directions. To do so, connect PT4 to different corner points; remove the plug-in module with cable if necessary.
- Establish a single-pole connection between PT4 and GND.
Faults to **LED4** (electric fields) and to **LED5** depending on the injection point (disturbance current)

Note:

Depending on the level of the line which is interfered with, the disturbance quantity must have a certain polarity:

- Low level: The disturbance pulses must be positive (line to LED4)
- High level: The disturbance pulses must be negative (line to LED5 changes its level at approx. 0.5 Hz and thus causes a different susceptibility).



Optical Fiber Probe (digital OSE)

Isolated measurement of digital signals during burst / ESD tests


Main usage:

Monitoring of modules such as watchdog, reset, chip-select lines



Plug the S21 or S25 sensor into socket 4 and connect to the oscilloscope via an optical fiber and optical receiver.

Generate electric fields by establishing a single-pole connection between SGZ 21 or PT4 and GND or using the ES 05 E field source or P21 E-field pulser.

Oscilligraph the signal.




Oscillographed disturbance pulse:
A 5 V pulse of differing width is displayed depending on the pulse expansion set on the optical receiver



Attention: Observe the switch position on the sensor:
The output signal is negated or not negated.


Optical Fiber Probe (analog A)

- Plug the AS 100 or AS 110 sensor into socket 3.
- Connect it to the oscilloscope via an optical fiber and optical receiver.
- Oscillograph the signal.




Attention:

The AE 100 optical receiver always has an output voltage range of 0 to 10 V.
Observe the switch position on the sensor and take the divider factor into consideration if necessary.





Interference to useful signal during radiated RF emission

Fault localisation with RF generator, power amplifier and RF near-field probe (as a field source)



Variation:

- Coupling with RF R400
- Lower susceptibility when coupled in via RF E05



Interference to supply voltage during RF coupling

Fault localisation with RF generator, power amplifier and RF near-field probe (as field source)

Attention!



Cyclically check the temperature of the probe heads and interrupt the measurement if necessary to cool them.

Function-related disturbances can be emitted during these measurements. (The DUT is excited to oscillate and acts as a sending aerial.)

Cables which are connected to the DUT modify the transient currents flowing through the DUT and thus influence the measurement result.

Interference through RF

Coupling with RF R400 probe at 200 - 250 MHz with 1 W and 1 kHz AM



+5 V supply voltage during RF coupling measured with AS 100 or AS 110 sensor on socket 1

Measurement technology - Disturbance emission

RF Near-Field Probes





Measurement of the magnetic and electric RF fields on the module


Two tasks:

- Measuring the field intensity, evaluation in the frequency range
- Measuring the field line orientation

Fault localisation procedure:


1. Measuring the fields on GND, cables and structural metal parts
2. Tracking these fields with smaller and smaller probes down to the field source on the module






Currents flowing on signal lines

Measurement with RF U2.5 probe





RF current flows to GND (intense magnetic field) through the capacitor at the end of the signal line, the electric field is dampened.



RF current is dampened through the resistor at the end of the signal line, coupling out of an electric field is intensified.

Electric fields on signal lines


Measurement with RF E05 probe




LF Near-Field Probes

- LF probes are only magnetic field probes
- Applicable in the frequency range between 100 kHz and 50 MHz
- Main field of application:
 - Power electronics
 - Switching transformers


Comparison of RF and LF probes in the frequency range up to 5 MHz:



LF R400 to GND



RF R400 to GND





ESA1 Emission Development System

Measurement with HFW 21

- Transient currents in D10 generate voltage differences in the GND system.
- The voltage differences couple in neighbouring metal parts (e.g. metal enclosures, shielding) and thus cause disturbance emissions



Measurement set-up:

- Connect HFW 21 to a spectrum analyser via a BNC-SMB cable and the PA 203 preamplifier.
- Connect the GND of D10 to the HFW 21 COM port via a short cable and an adapter socket (green with plug pin).
- HFW 21 must make contact with the Ground Plate.
- If D10 is switched off, the shielding effect of the tent can be demonstrated - D10 acts as a receiving aerial for disturbances from the surroundings.



Measurement without plug-in board: Only HFW 21 is connected to GND and measures transient currents between D10 and the Ground Plate GP 23.

Parameter: Distance between D10 (DUT) and the Ground Plate GP 23 (e.g. shielding enclosure)



Measurement with plug-in board: Only HFW 21 is connected to GND and measures transient currents between D10 and the Ground Plate GP 23.

Parameter: Distance and position of the plug-in board relative to the Ground Plate GP 23